

CS 736

Image Deblurring

By:
Aadish Sethiya (210100001)
Harshit Agarwal (210020054)


Introduction

- Medical imaging is vital for accurate diagnosis and treatment planning.
- Image quality is often compromised by motion blur, noise, and hardware limitations.
- Deblurring algorithms help recover sharp, clear images from degraded inputs.
- This study explores and compares three key deblurring techniques for medical use.



Background

- Degraded images are modeled as the convolution of a sharp image with a Point Spread Function (PSF), plus noise.
- Deblurring involves reversing this process to estimate the original image.
- Deterministic deblurring methods provide stable and reproducible outcomes.
- Such methods are preferred in clinical settings for their reliability and interpretability.



Problem Description


Image Deblurring Setup

- **Goal:** Restore a sharp image \mathbf{I} from a blurred observation \mathbf{B} , given the Point Spread Function (PSF) \mathbf{P}

$$\mathbf{B} = \mathbf{I} * \mathbf{P} + \mathbf{N}$$

- $*$ denotes convolution operation
- \mathbf{N} is additive noise (Gaussian or Poisson)

Challenge: Invert the convolution process while effectively handling noise



Deblurring Algorithms

Richardson-Lucy Deconvolution

- Iterative algorithm for images with **Poisson noise**
- Based on **maximum likelihood estimation**

$$I^{(t+1)} = I^{(t)} \cdot [(B / (I^{(t)} * P + \epsilon)) * P^*]$$

- $I^{(t)}$: Current image estimate
- B : Observed blurred image
- P : Known PSF, P^* : 180° rotated PSF
- ϵ : Small constant to prevent division by zero

Note: Produces sharp results but sensitive to noise and iteration count

Algorithm Steps

- 1 Initialize with uniform or blurred image
- 2 Compute blurred estimate ($I^{(t)} * P$)
- 3 Calculate error ratio ($B / \text{blurred estimate}$)
- 4 Convolve with flipped PSF (P^*)
- 5 Multiply result with current estimate
- 6 Update to new estimate $I^{(t+1)}$

↻ Repeat steps 2-6


Stop on convergence or fixed iteration count

Wiener Deconvolution

- Operates in the **frequency domain** to restore blurred images
- Minimizes **mean square error** between original and estimated image

$$\tilde{I}(u, v) = [H^*(u, v) / (|H(u, v)|^2 + K)] \cdot B(u, v)$$

- $\tilde{I}(u, v)$, $B(u, v)$: Fourier transforms of restored/blurred images
 - $H(u, v)$: Fourier transform of PSF
 - $H^*(u, v)$: Complex conjugate of $H(u, v)$
 - K : Noise-to-signal power ratio
- Final image obtained via **inverse Fourier transform**
- Effective for **Gaussian noise**; fast, non-iterative deblurring



Key Advantages

Fast
Non-iterative

Optimal
Minimizes MSE

Robust
Handles noise

Total Variation (TV) Regularization

- Solves an optimization problem:

$$\min_I \|I * P - B\|^2 + \lambda \cdot TV(I)$$

- Balances data fidelity with edge-preserving regularization
- Uses iterative gradient descent for optimization

$$I^{(t+1)} = I^{(t)} - \eta \cdot [(I^{(t)} * P - B) * P^* + \lambda \cdot \nabla TV(I^{(t)})]$$

- η : Step size
- λ : Regularization parameter
- $\nabla TV(I)$: Gradient encouraging smooth regions while preserving edges

Optimization Process

- 1 Initialize with blurred image or estimate
- 2 Calculate data fidelity: $(I^{(t)} * P - B) * P^*$
- 3 Compute TV gradient: $\nabla TV(I^{(t)})$
- 4 Apply regularization weight λ
- 5 Update estimate with step size η

Repeat steps 2-5

Until convergence or max iterations

Key Benefit: Preserves anatomical boundaries in medical images while reducing noise




Results

- Experiments conducted on three medical images:
 - X-Ray Lungs
 - Chest CT Scan
 - Brain MRI
- Images were synthetically blurred with a known PSF and corrupted with Gaussian noise.
- Applied three deblurring algorithms:
 - Richardson-Lucy Deconvolution
 - Wiener Deconvolution
 - TV Regularized Deblurring
- Evaluation methods:
 - Visual inspection
 - LPIPS metric to assess perceptual similarity



Brain MRI Image

Wiener Deconvolution



Effect of Kernel Size



14



Kernel - 30, Angle - 45, Noise Sigma - 3






Kernel - 20, Angle - 45, Noise Sigma - 3



Brain MRI Image

Richardson Lucy
Deconvolution



Effect of Kernel
Size



15



Kernel - 30, Angle - 45, Noise Sigma - 3






Kernel - 20, Angle - 45, Noise Sigma - 3



Brain MRI Image

Total Variation
Algorithm



Effect of Kernel
Size



16



Kernel - 30, Angle - 45, Noise Sigma - 3






Kernel - 20, Angle - 45, Noise Sigma - 3



Brain MRI Image

Wiener Deconvolution



Effect of Angle



Kernel - 10, Angle - 45, Noise Sigma - 3



Kernel - 10, Angle - 90, Noise Sigma - 3





Kernel - 10, Angle - 0, Noise Sigma - 3


Brain MRI Image

Richardson Lucy
Deconvolution


Effect of Angle



18



Kernel - 10, Angle - 90, Noise Sigma - 3






Kernel - 10, Angle - 0, Noise Sigma - 3



Brain MRI Image

Total Variation
Algorithm


Effect of Angle



19



Kernel - 10, Angle - 90, Noise Sigma - 3








Kernel - 10, Angle - 0, Noise Sigma - 3



Brain MRI Image

Wiener
Deconvolution

Effect of Noise
Sigma



Kernel - 10, Angle - 45, Noise Sigma - 5






Kernel - 10, Angle - 45, Noise Sigma - 1


Brain MRI Image

Richardson Lucy
Deconvolution

Effect of Noise
Sigma



Kernel - 10, Angle - 45, Noise Sigma - 5






Kernel - 10, Angle - 45, Noise Sigma - 1



Brain MRI Image

Total Variation
Algorithm



Effect of Noise
Sigma



22




Kernel - 10, Angle - 45, Noise Sigma - 5




Kernel - 10, Angle - 45, Noise Sigma - 1

Wiener Deconvolution

Kernel Size: 20
Angle: 45
Noise Sigma: 3



Brain MRI Image




Chest CT Image




Chest X-Ray Image

Richardson Lucy Deconvolution

Kernel Size: 20
Angle: 45
Noise Sigma: 3



Brain MRI Image




Chest CT Image



Chest X-Ray Image

Total Variation Algorithm

Kernel Size: 20
Angle: 45
Noise Sigma: 3



Brain MRI Image



Chest CT Image



Chest X-Ray Image

Effect of Kernel Size on Deblurring




- Kernel sizes tested: $k = 10, 20, 30$
- Wiener Deconvolution
 - Performance drops with increasing kernel size
 - Susceptible to noise amplification due to weak frequency response
- Richardson-Lucy
 - Better with large kernels, but needs more iterations
 - More sensitive to noise as kernel size increases
- Total Variation
 - Most robust to large kernels
 - Preserves edge sharpness with slight smoothing trade-off

Effect of Noise Level on Deblurring

- Noise levels tested: $\sigma = 1, 3, 5$
- Wiener Deconvolution
 - Unstable with increasing noise (LPIPS: 0.06 to 0.36)
 - Amplifies noise, causing artifacts and detail loss.
- Richardson-Lucy
 - Amplifies noise over iterations (LPIPS: 0.10 to 0.32)
 - Requires early stopping or denoising, especially at $\sigma = 5$.
- Total Variation
 - Best in high-noise settings (LPIPS: 0.12 to 0.29)
 - Preserves structure with slight smoothing at $\sigma = 5$.

Effect of PSF Orientation on Deblurring

- PSF orientations tested: $\alpha = 0^\circ, 45^\circ, 90^\circ$
- Wiener Deconvolution
 - Largely isotropic in frequency domain
 - Minor sensitivity due to numerical artifacts
- Richardson-Lucy
 - Performs well across orientations
 - May introduce directional artifacts at higher angles
- Total Variation
 - Consistent across directions
 - Slight directional bias but more isotropic than RL



Observations

Visual Quality & Restoration

Kernel Size: 20, Angle: 45, Noise Sigma: 3

- Wiener Deconvolution
 - Partial blur reduction but limited detail recovery
 - Ringing artifacts and background distortions visible
 - LPIPS: 0.30 – moderate perceptual improvement
- Richardson-Lucy Deconvolution
 - Sharpest output with clear anatomical structures
 - Amplifies noise in flat/background regions
 - LPIPS: 0.28 – lowest, highest perceptual similarity
- Total Variation Deblurring
 - Best balance between noise suppression and edge preservation
 - Smooths noise while maintaining structure
 - Slight over smoothing in low-contrast areas
 - LPIPS: 0.30 – matches Wiener, but better qualitative sharpness

Computation Time & Efficiency

- Total Variation Deblurring
 - Slowest method due to iterative gradient descent and regularization
 - Requires more computation for convergence
- Richardson-Lucy Deconvolution
 - Moderate runtime
 - Iterative but reasonably efficient for a limited number of iterations
- Wiener Deconvolution
 - Fastest among all methods
 - Single-pass frequency-domain filtering enables quick processing

Overall Trade-offs

- Wiener Deconvolution
 - Best for speed and noise suppression
 - Suitable for real-time or low-resource scenarios
- Richardson-Lucy Deconvolution
 - Ideal for enhancing fine details
 - Trades off with higher noise sensitivity
- Total Variation Deblurring
 - Best balance for medical imaging
 - Combines edge preservation with noise reduction
 - Acceptable runtime for high-quality restoration

A detailed report along with all the results can be found at the link below:

<https://github.com/AadishSethiya/CS-736-Project.git>

Thank You!